

CABIN FILTER: REMOVAL - REFITTING



Note, one or more warnings are present in this procedure



WARNING



■ To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair:

- [Air conditioning: Precautions for the repair](#) ,
- [Vehicle: Precautions for the repair](#) .

Locations and specifications (tightening torques, parts to always be replaced, etc.) [\(see 61A, Heating, Passenger compartment heating and ventilation assembly: Exploded view\)](#) .

REMOVAL

1. REMOVAL PREPARATION OPERATION

- Unclip the centre console trim on the right-hand side.

2. REMOVAL OPERATION

- Remove the cabin filter access flap bolts [\(see 61A, Heating, Passenger compartment heating and ventilation assembly: Exploded view\)](#) .
- Unclip the cabin filter access flap [\(see 61A, Heating, Passenger compartment heating and ventilation assembly: Exploded view\)](#) .

Note:



Foreign bodies (leaves, insects, etc.) are likely to accumulate in the cabin filter.
Remove the filter with care so as to prevent foreign bodies getting into the evaporator.

- Mark the cabin filter fitting direction.
- Remove the cabin filter [\(see 61A, Heating, Passenger compartment heating and ventilation assembly: Exploded view\)](#) .

REFITTING

1. REFITTING PREPARATION OPERATION

- Check there are no foreign bodies in the passenger compartment filter housing and clean thoroughly if necessary.

2. REFITTING OPERATION

- Proceed in the reverse order to removal.



Repair-30x02x01x14-01x37-1-37-1.xml



XSL version : 3.02 du 22/07/11