




Illustration key: [Description](#) .

For fastenings with no specified tightening torque values, refer to the Table of Standard Torques: [Tightening torques: General information](#) .

Marks	Designations	Informations
1	Electric traction motor assembly	Electric powertrain assembly : Removal - Refitting
2	Right-hand suspended engine mounting	(see 19D, Engine mounting, Right-hand suspended engine mounting: Removal - Refitting)
3	Bracket lower engine tie-bar rod	(see 19D, Engine mounting, Lower engine tie-bar: Removal - Refitting)
4	Lower engine tie-bar	(see 19D, Engine mounting, Lower engine tie-bar: Removal - Refitting)
5	Front axle subframe	(see Front axle subframe: Removal - Refitting)
6	Engine tie-bar mounting	(see 19D, Engine mounting, Lower engine tie-bar: Removal - Refitting)
7	Bracket axis Left-hand	(see 19D, Engine mounting, Left-hand suspended engine mounting: Removal - Refitting)
8	Gearbox support	(see 19D, Engine mounting, Left-hand suspended engine mounting: Removal - Refitting)
9	Support of left-hand suspended engine mounting	(see 19D, Engine mounting, Left-hand suspended engine mounting: Removal - Refitting)
10	Left-hand suspended engine mounting	(see 19D, Engine mounting, Left-hand suspended engine mounting: Removal - Refitting)



Repair-10x04x01x04-02x50-1-9-1.xml



mcx30.com