

FAN ASSEMBLY: REMOVAL - REFITTING



Note, one or more warnings are present in this procedure



WARNING



■ To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair:

- [Air conditioning: Precautions for the repair](#) ,
- [Vehicle: Precautions for the repair](#) .

Locations and specifications (tightening torques, parts to always be replaced, etc.) ([see 61A, Heating, Passenger compartment heating and ventilation assembly: Exploded view](#)) .

REMOVAL

1. REMOVAL PREPARATION OPERATION

- Remove the glovebox [Dashboard assembly: Exploded view](#) .

2. REMOVAL OPERATION

- Disconnect the passenger compartment fan assembly connector ([see 61A, Heating, Passenger compartment heating and ventilation assembly: Exploded view](#)) .
- Remove [\(see 61A, Heating, Passenger compartment heating and ventilation assembly: Exploded view\)](#) :
 - the passenger compartment fan assembly bolts,
 - the passenger compartment fan assembly.

REFITTING

- Proceed in the reverse order to removal.



mcx30.com