


GEARCONTROL ASSEMBLY:EXPLODED VIEW



163237

Illustration key: Description .

For fastenings with no specified tightening torque values, refer to the Table of Standard Torques: [Tightening torques: General information](#) .

Marks	Designations	Informations
1	Gear level knob	(see 37A, Mechanical component controls, Electric traction reduction gearing control unit : Removal - Refitting)
2	Nut	
3	Electric traction reduction gearing control unit	(see 37A, Mechanical component controls, Electric traction reduction gearing control unit : Removal - Refitting)
4	Electric traction reduction gearing control cable	(see 37A, Mechanical component controls, Electric traction reduction gearing control cable : Removal - Refitting)
5	Electric traction reduction gearing	
6	Cable sleeve stop screw	
7	Electric traction reduction gearing control cable stop	
8	Tunnel seal screw	



mcx30.com