

PEDAL ASSEMBLY: EXPLODED VIEW




Note, one or more warnings are present in this procedure



WARNING

- To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair:
 - [\(see 37A. Mechanical component controls, Pedal assembly mechanism: Precautions for the repair\)](#) ,
 - [Vehicle: Precautions for the repair](#) .



[Illustration key: Description](#) .

For fastenings with no specified tightening torque values, refer to the Table of Standard Torques [Tightening torques: General information](#) .

Marks	Designations	Informations
1	Brake pedal - servo rod connecting pin	
2	Accelerator pedal	(see Accelerator pedal: Removal - Refitting)
3	Accelerator pedal rubber pad	
4	Gas-pedal stopper	
5	Brake pedal	(see 37A, Mechanical component controls, Brake pedal: Removal - Refitting)
6	Brake pedal rubber pad	
7	Brake pedal switch	(see 37A, Mechanical component controls, Pedal switches: Adjustment)



Repair-30x03-02x50-1-5-1.xml



XSL version : 3.02 du 22/07/11

mcx30.com