

REAR AXLE



Note, one or more warnings are present in this procedure



1. WHEEL ALIGNMENT: MEANING OF SYMBOLS




CAUTION

■ Symbols used by RENAULT:


- toe-out: -
- toe-in: +

2. WHEEL ALIGNMENT



Value	Position of vehicle
-0°25' ± 15'	Vehicle in running order

3. CAMBER



Value	Position of vehicle
-0°66' ± 20'	Vehicle in running order



mcx30.com