

REAR BENCH SEAT ASSEMBLY: EXPLODED VIEW




Illustration key: [Description](#) .

For fastenings with no specified tightening torque values, refer to the Table of Standard Torques [Tightening torques: General information](#) .

Marks	Designations	Informations
1	Rear bench seatback frame	
2	Rear bench seat base frame	(see 76A, Rear seat frames and mechanisms, Rear bench seat base: Removal - Refitting)
3	Rear seat lock bar	
4	Rear seat lock bar	
5	Unlocking control of rear bench seatback	
6	Unlocking control of rear bench seatback	
7	Unlocking control of rear bench seatback	
8	Unlocking control of rear bench seatback	
9	Rear bench seat headrest guide	
10	Rear bench seat headrest guide	
11	Rear bench seat headrest guide	
12	Rear bench seat headrest guide	
13	Rear bench seat headrest guide	
14	Rear bench seat headrest guide	
15	Rear bench seat headrest	
16	Rear bench seat central headrest	
17	Rear bench seat headrest	
18	Rear bench seat belt	
19	Rear bench seat belt	
20	Rear bench seat belt	
21	Rear bench seat belt	
22	Rear bench seat belt	
23	Rear bench seat belt buckle	
24	Rear bench seat belt buckle	




Illustration key: [Description](#) .

For fastenings with no specified tightening torque values, refer to the Table of Standard Torques [Tightening torques: General information](#) .

Marks	Designations	Informations
1	Rear bench seatback cover	
2	Rear bench seat base cover	
3	Rear bench seatback foam	
4	Rear bench seat base foam	
5	Rear bench seat mounting on body	



Repair-70x13x02-02x50-1-6-1.xml



XSL version : 3.02 du 22/07/11