

TYRE: PRECAUTIONS FOR THE REPAIR



Note, one or more warnings are present in this procedure



1. CLEANLINESS

 Clean:

- the tyre bead,
- the tyre bead/wheel rim contact surface.

Remove any stones trapped in the tyre tread.

2. GENERAL RECOMMENDATIONS



CAUTION

If checking the pressure when hot, increase the tyre inflation pressure by 0.2 to 0.3 bar above the recommended pressure.



CAUTION

In order to remove any flat spots on the tread after the vehicle has stopped, it is essential to carry out a road test for a minimum distance of 1.2 miles (2 km) before balancing the wheels.



CAUTION

To avoid detachment of the balance weights, use only weights which correspond to the vehicle wheel rims.

