

SECTION 501-10: Seating
REMOVAL AND INSTALLATION

2014 F-150 Workshop Manual
Procedure revision date: 10/25/2013

Seat Backrest Thermo-Electric Device

Removal and Installation

NOTE: For parts identification and location, refer to [Seat — Exploded View, Front](#) in this section.

1. Position the seat backrest fully forward.
 2. Release the backrest cover J-clip and unzip the 2 zippers.
 3. Disconnect the Thermo-Electric Device (TED) electrical connector.
 4. Detach the pin-type retainer attaching the TED duct to the backrest frame.
 5. Un-hook the TED from the backrest support wire and remove.
 - If equipped with power lumbar, note cable routing for correct installation.
 6. To install, reverse the removal procedure.
-