

	Stalled	
B1988	Pedal Position Forward Switch Circuit Short to Battery	GO to Pinpoint Test B
B1989	Pedal Position Rearward Switch Circuit Short to Battery	GO to Pinpoint Test B
B1991	Pedal Forward / Rearward Potentiometer Feedback Circuit Short to Battery	GO to Pinpoint Test D
B2275	Pedal Forward / Rearward Potentiometer Feedback Circuit Short to Ground	GO to Pinpoint Test D
-	All Other DSM Diagnostic Trouble Codes (DTCs)	REFER to: Front Seats .

DIAGNOSIS AND TESTING > HYDRAULIC BRAKE ACTUATION > SYMPTOM CHARTS

Symptom Chart - Adjustable Pedals Without Memory Feature

Diagnostics in this service information assume a certain skill level and knowledge of Ford-specific diagnostic practices. REFER to: Diagnostic Methods .

Symptom	Possible Sources	Action
Adjustable pedals are inoperative or do not operate correctly	Refer to the Pinpoint Test	GO to Pinpoint Test A

Symptom Chart - Adjustable Pedals With Memory Feature

Diagnostics in this service information assume a certain skill level and knowledge of Ford-specific diagnostic practices. REFER to: Diagnostic Methods .

Symptom	Possible Sources	Action
A module does not respond to the diagnostic scan tool	Fuse Wiring, terminals or connectors DSM concern	REFER to: Communications Network .
Adjustable pedals are inoperative or do not operate correctly - using the adjustable pedal control switch	Refer to the Pinpoint Test	GO to Pinpoint Test B
Adjustable pedals are inoperative or do not operate correctly - using the memory SET switch buttons	Refer to the Pinpoint Test	GO to Pinpoint Test C