

PUBLISHED: 24-MAR-2020  
2020.0 DEFENDER (LE), 502-03

TOWBAR

# DEPLOYABLE TOWBAR CONTROL MODULE (G2416673)

mcx30.com

## GENERAL EQUIPMENT

## EQUIPMENT NAME

Jaguar Land Rover approved diagnostic equipment

## REMOVAL


 NOTES:

- This procedure contains some variation in the illustrations depending on the vehicle specification, but the essential information is always correct.
- This procedure contains illustrations showing certain components removed to provide extra clarity.

1. Disconnect the startup battery ground cable.


Refer to: [Startup Battery Disconnect and Connect](#) (414-00 Battery and Charging System - General Information, General Procedures).

- 2.




Remove the loadspace floor trim.

3.





Remove the stowage compartment.

4.



- Disconnect the 3 electrical connectors from the deployable Tow Bar Control Module (TBM).
- Disconnect the electrical connector from the speaker.
- Release the speaker wiring harness from the clip.



- Remove the 2 nuts.
- Remove the speaker and bracket assembly.
- Remove the deployable TBM.

## INSTALLATION

1.

- Install the deployable TBM.
- Install the bracket and speaker assembly.
- Install and tighten the 2 nuts.  
*Torque: 5.4Nm*
- Connect the 3 electrical connectors to the deployable TBM.
- Connect the electrical connector to the speaker.
- Secure the speaker wiring harness to the clip.

2.

Connect the startup battery ground cable.

Refer to: [Startup Battery Disconnect and Connect](#) (414-00 Battery and Charging System - General Information, General Procedures).

3.

Install the stowage compartment.

4.

Install the loadspace floor carpet.

5.



### NOTES:

- This step is only required if a new component is installed.
  - SRO to be claimed separately.
- 
- Use the Jaguar Land Rover (JLR) approved diagnostic equipment to configure the TBM.  
*General Equipment: [Jaguar Land Rover approved diagnostic equipment](#)*
  - Follow all on-screen instructions to complete this task.